

19425 SW 89TH AVE
TUALATIN, OR 97062
PHONE: (503)692-5995
FAX: (503)885-0417
EMAIL: SALES@ADVANCEDDYNAMO.COM

EMAIL: SALES@ADVANCEDDYNAMO.COM INFO@ADVANCEDDYNAMO.COM SERVICE@ADVANCEDDYNAMO.COM

FUEL RETURN LINE INSTALLATION INSTRUCTIONS

Required for all Advanced Dynamo Industries (ADyI) 500 Series gasoline and diesel generators installed into a Winnebago commercial shell.




Directly behind the Fuel Fill Gas Cap (picture A) locate the large diameter Fuel Fill Hose and the smaller diameter <u>Fuel</u> <u>Vent Hose</u> (picture B).



Α



In the ADyl supplied <u>Fuel Return Line Kit</u> (picture C), locate the <u>1" x ¼" x 1" Brass Vent</u> <u>Tee</u> (picture D).



C



Cut the 1" **Fuel Vent Hose** and install the **Brass Vent Tee** (**picture D**) with the ¼" hose barb pointing <u>toward</u> the generator and secure with the ADyl supplied **Hose Clamps** (**picture E**).



E



Run the ADyl supplied <u>%" Fuel Return Line</u> from the Generator Fuel Plate-Out barbed fitting (picture F) forward to the previously mounted <u>Brass Vent Tee</u>'s %" hose barb along the chassis frame. Follow the same route as the main fuel line to the generator. Cut the <u>%" Fuel Return Line</u> to the length needed and secure to both barbed fittings with the ADyl supplied <u>Hose Clamps</u> (picture G). Finally, secure the <u>Fuel Return Line</u> every 18" – 24" with the ADyl supplied <u>Plastic Zip Ties</u>.

G

^{*}For additional clarification please reference the attached <u>416 Fuel System and Fuel Return Kit Schematic</u>.